

## 4x4 Portable Base Capacity Chart (Empty Base Weight 1800)

REACH	TOTAL BASE WEIGHT (LBS)						
	3800	4300	4800	5300	5800	6300	6800
8 ft.	248	281	313	346	379	375	444
9 ft.	213	241	269	297	325	322	381
10 ft.	186	211	235	260	284	282	333
11 ft.	166	187	209	231	253	251	296
12 ft.	149	169	188	208	228	226	267
13 ft.	136	153	171	189	207	205	243
14 ft.	124	141	157	173	190	188	223
15 ft.	115	130	145	160	175	174	205

## 3x3 Portable Base Capacity Chart (Empty Base Weight 1200)

REACH	TOTAL BASE WEIGHT (LBS)		
	3200	3700	4200
8 ft.	148	171	194
9 ft.	128	148	168
10 ft.	113	131	148
11 ft.	101	117	133
12 ft.	91	106	120
13 ft.	83	97	110
14 ft.	77	89	101
15 ft.	71	82	93

### AIMCO Portable Base with:

Structural steel ballast base  
 Measuring 3ft. x 3ft. x 2ft. OR  
 4ft. x 4ft. x 2 ft. deep.  
 Fork pockets internal to base  
 Four leveling pads  
 It is required that the ballast base be  
 filled with steel shot to a pre-determined  
 weight to provide the required safety factor  
 (total weight including base).  
 Steel shot supplied by other  
 Empty ballast weight 4x4 = 1,800 lbs.  
 Empty ballast weight 3x3 = 1,200 lbs.  
 Mesh S70 steel shot recommended.

